


INTERACTIVE CAT TOY BALL


User Manual

【Operation Instructions】

1. Insert and fix the base of feather into the top hole of tumbler ball. When you can lift the ball by holding the feather, it means that they are assembled together well.
2. Press "⏻" to choose appropriate mode:
 - a. Press "⏻" for 2s to turn the ball on and activate run & light mode, it can move forward, backward, rotate on the spot, automatically turn a corner.
 - b. Press "⏻" again to enter run & light & sound mode.
 - c. Press "⏻" to change modes at your will. Long press "⏻" for 2s to turn it off.



① Insert feather base



② Long press "⏻" for 2s to turn it on/off

3. The ball only work continuously for 75s once under any mode. If the ball automatically stopped, you can activate it by touching it or making sounds nearby, otherwise the ball will be turned off automatically after 6 hours. (Note: the LED light will flash once every 3s.)
4. The battery endurance depends on the frequency of cat playing with the ball. The normal endurance time is about 1.5-10 hours.
5. When the ball slows down, runs intermittently, or cannot be activated after stopping, which means that the battery power is running out, please connect to power supply through USB cable. The LED light flashes when charging, turns into flashing colorful light after being fully charged.

【Caution】

1. Please turn the product off before charging and do not use it while charging.
2. Please remove the package and label before giving to your pet.
3. Please play on flat dry ground, or it may affect the ball rolling or make roll get stuck.
4. Recommended that do not play the product on plush carpet.
5. Do not wash the product with water, please wipe the stain on surface with cloth.
6. If the accessories are broken during use, you can choose to buy accessories alone.
7. Feather accessories have passed the safety test and been sterilized by high temperature, please feel easy to use.

⚠ WARNING

1. This product is only designed for pets but not for kids, please keep the product away from children to avoid accidental injury.
2. Please do not allow pets playing it if the product is damaged or deformed.
3. Please dispose of the discarded product properly, improper disposing will affect environment.
4. For supervised play only.

Model: MDE1600

FCC CE RoHS



Made in China

