


- NL** Slagmoersleutel
- GB** Impact wrench
- D** Schlagschrauber
- F** Boulonneuse
- I** Avvitatori ad Impulso
- DK** Slagnøgle
- N** Muttertrekere

- RC2690**
- RC2690**
- RC2690**
- RC2690**
- RC2690**
- RC2690**
- RC2690**



Index	Parts No.	Description	Quantity
1	RPSC0985TA01	Oil Seal	1
2	RPSC0985TA02	Regulator Knob	1
3	RPSC0985TA03	Hammer Case	1
4	RPSC0985TA04	Bushing	1
5	RPSC0985TA05	Anvil Collar (3/8"DR)	1
6	RPSC0985TA06	O-Ring (3.8*1.9)	1
7	RPSC0985TA07	Anvil (3/8" DR)	1
8	RPSC0985TA08	Hammer Pin	2
9	RPSC0985TA09	Hammer Dog	2
10	RPSC0985TA10	Hammer Cage	1
11	RPSC0985TA11	Front Gasket	1
12	RPSC0985TA12	Motor Housing	1
13	RPSC0985TA13	O-Ring	1
14	RPSC0985TA14	Washer	1
15	RPSC0985TA15	Ball Bearing	1
16	RPSC0985TA16	Cylinder	1
17	RPSC0985TA17	Spring Pin	1
18	RPSC0985TA18	Rotor Blade	6
19	RPSC0985TA19	Rotor	1

Index	Parts No.	Description
20	RPSC0985TA20	Rear Plate
21	RPSC0985TA21	Ball Bearing
22	RPSC0985TA22	Rear Gasket
23	RPSC0985TA23	Rear Cover
24	RPSC0985TA24	Screw
25	RPSC0985TA25	O-Ring
26	RPSC0985TA26	Steel Ball
27	RPSC0985TA27	Spring
28	RPSC0985TA28	Reverse Valve (3/8"DR)
29	RPSC0985TA29	Trigger
30	RPSC0985TA30	O-Ring
31	RPSC0985TA31	Muffler
32	RPSC0985TA32	Retainer
33	RPSC0985TA33	Valve Stem
34	RPSC0985TA34	Spring
35	RPSC0985TA35	Exhaust Deflector
36	RPSC0985TA36	O-Ring
37	RPSC0985TA37	Washer
38A	RPSC0985TA38A	Hose Adaptor -18NPT
38B	RPSC0985TA38B	Hose Adaptor -19PT
38C	RPSC0985TA38C	Hose Adaptor -19PF ( BSP )

