


- NL TL804N
- GB TL804N
- D TL804N
- F TL804N

**Uitdeukset hydraulisch
Hydraulic body repair kit
Hydraulische Ausbeulsatz
Vérin carrossier hydraulique**




2013-02

**Know your body Repair Kit
4 TON**



Index	Parts No.	Description	Qty
1	TL804N01	Metal storage case	1
2	TL804N02	495mm Extension bar	1
3	TL804N03	418mm Extension bar	1
4	TL804N04	215mm Extension bar	1
5	TL804N05	125mm Extension bar	1
6	TL804N06	82mm Extension bar	1
7	TL804N07	Serrated cap	1
8	TL804N08	Spreading wedge	1
9	TL804N09	Rubber head	1
10	TL804N10	Base plate	1
11	TL804N11	Ram toe	1
12	TL804N12	Plunger toe	1
13	TL804N13	Cleft cap	1
14	TL804N14	"V" base	1
15	TL804N15	Male connector	1
16	TL804N16	4Ton pump unit	1
17	TL804N17	Ram unit	1
18	TL804N18	Hydraulic hose	1


**Parts Listing and Drawing
HYDRAULIC SPREADER ASSEMBLY**



Index	Parts No.	Description	Qty
S01	TL804NS01	Lower duck bill	1
S02	TL804NS02	Spring	1
S03	TL804NS03	Upper duck bill	1
S04	TL804NS04	Pivot pin	1
S05	TL804NS05	Cir clip	1
S06	TL804NS06	Piston	1
S07	TL804NS07	Cup seal	1
S08	TL804NS08	O-ring	1
S09	TL804NS09	End cap	1
S10	take TL810P42	Coupling ring	1
S11	take TL810P42	Coupling bolt	1
S12	take TL810P42	O-ring	1
S13	take TL810P42	Dust cap	1
	TL810P42	Set S10-S11-S12-S13	1

Index	Parts No.	Description	Qty
R01	TL804NR01	Cylinder	1
R02	TL804NR02	Retainer nut	1
R03	TL804NR03	Protecting cap	1
R04	TL804NR04	Screw	1
R05	TL804NR05	Spring	1
R06	TL804NR06	Hex Nut	1
R07	TL804NR07	Cir clip	1
R08	TL804NR08	O-ring	1
R09	TL804NR09	Washer (nylon)	1
R10	TL804NR10	Bushing	1
R11	TL804NR11	Half round ring	1
R12	TL804NR12	Ram	1
R13	TL804NR13	Spacing ring	1
R14	TL804NR14	Cir clip	1
R15	TL804NR15	Protecting cap	1
R16	TL804NR16	Screw	1

Spare parts listing



Index	Parts No.	Description	Qty
P01	TL804NP01	Pump housing	1
P02	TL804NP02	Filter	1
P03	TL804NP03	Seal	1
P04	TL804NP04	Reservoir and cap	1
P05	TL804NP05	Reservoir and cap	1
P06	TL804NP06	Pump foot	1
P07	TL804NP07	Hex nut	1
P08	TL804NP08	O-ring	1
P09	TL804NP09	Dip stick	1
P10	TL804NP10	Ball valve	1
P11	TL804NP11	Ball valve	1
P12	TL804NP12	Spring	1
P13	TL804NP13	Overload screw	1
P14	TL804NP14	Release valve stem	1
P15	TL804NP15	Seal	1
P16	TL804NP16	O-ring	1
P17	TL804NP17	Back up ring	1
P18	TL804NP18	Clamping nut	1
P19	TL804NP19	O-ring	1

Index	Parts No.	Description	Qty
P20	TL804NP20	Back up ring	1
P21	TL804NP21	Piston	1
P22	TL804NP22	Handle bracket	1
P23	TL804NP23	Piston pin	1
P24	TL804NP24	Bracket pin	1
P25	TL804NP25	Cir clip	1
P26	TL804NP26	Pump handle	1
P27	TL804NP27	Handle grip	1
P28	TL804NP28	Hose	1
P29	TL804NP29	Coupling	1
P30	TL804NP30	Dust cap	1
P31	TL804NP31	Ball valve	1
P32	TL804NP32	Spring plunger	1
P33	TL804NP33	Spring	1
P34	TL804NP34	O-ring	1
P35	TL804NP35	Screw(Safety valve)	1
P36	TL804NP36	Plastic cap	1