

Zwischenhebel-Feder-Werkzeug für BMW




ALLGEMEINE INFORMATION

Dieses Werkzeug ist konzipiert zur Demontage und Montage der Druckfedern am Ventil-Zwischenhebel, es sorgt für schnelle, einfache und sichere Handhabung dieser kräftigen Federn. Das Werkzeug ist geeignet für BMW Motoren N20, N51, N52, N52K, N52T, N55 und zu verwenden wie OEM 114270.

WICHTIGER HINWEIS

Diese Anleitung dient als Kurzinformation und ersetzt keinesfalls ein Werkstatthandbuch. Verwenden Sie immer fahrzeugspezifische Serviceliteratur, dieser entnehmen Sie bitte technische Angaben wie z.B. Drehmomentwerte, spezielle und allgemeine Hinweise zur Demontage und Montage.

ANWENDUNG



Intermediate Lever Spring Tool for BMW



GENERAL INFORMATION

This tool is designed for disassembling and assembling of springs on the valve-intermediate lever, The tool allows fast, easy and safe handling of these strong springs.

The tool is suitable for BMW engines N20, N51, N52, N52K, N52T, N55 and it can be used like OEM 114270.

IMPORTANT NOTE

This manual is just brief information and will not replace a workshop manual.

Always consult specific service literature for special and general information about torques, mounting and disassembling.

APPLICATION

