


**NL** Ratelsleutel  
**GB** Ratchet  
**D** Ratschenschrauber  
**F** Clés à Rochet  
**I** Cricchetti ad aria  
**DK** Skraldenøgler  
**N** Skraller

RC 468  
 RC 468  
 RC 468  
 RC 468  
 RC 468  
 RC 468  
 RC 468



2011-04



Index	Parts No.	Description	Quantity
1	RPHD12001	Motor Housing	1
2	RPHD12002	Hose adapter	1
3	RPSP25220	Spring pin	1
4	RPAR38005	Throttle lever	1
5	RPVP70041	Valve screw	1
6	RPOR23441	O-ring	1
7	RPVP70037	Valve spring	1
8	RPOR3941	O-ring	1
9	RPVP70035	Valve stem	1
10	RPCP70011	Bearing cap	1
13	RPBB608ZZ	Ball bearing	1
14	RPHD12014	Rear end plate	1
15	RPHD12015	Rotor	1
16	RPHD12016	Rotor blade	4
17	RPSP30060	Spring pin	1
18	RPHD12018	Cylinder	1
19	RPHD12019	Front end plate	1
20	RPBB6000ZZ	Ball bearing	1
21	RPHD12021	Clamp nut	1
22	RPHD12022	Washer	1
23	RPBB6200ZZ	Ball bearing	1
24	RPHD12024	Internal gear	1
25	RPHD12025	Idler gear plate	1

Index	Parts No.	Description	Quantity
26	RPHD12026	Idler gear	3
27	RP0530141	Steel ball	3
28	RPHD12028	Ratchet housing	1
29	RPHD12029	Needle bearing	1
30	RPSP25060	Spring pin	1
31	RPHD12031	Crank shaft	1
32	RPHD12032	Drive bushing	1
33	RPHD12033	Yoke	1
34	RPHD12034	Reverse button	1
35	RPNR60160	Needle roller	1
36	RPHD12036	Reverse spring	1
37	RPHD12037	Lock pin	1
38	RPHD12038	Pawl	1
39	RPHD12039	Ratchet anvil +41+46	1
40	RPHD12040	Spring	2
42	RPHD12042	Thrust washer	1
43	RPRTW036	Internal stop ring	1
44	RPNR50223	Needle roller	3
45	RPAP70030	Bushing	1
47	RPOR5334	O-ring	1
49	RPAP70034	Air regulator	1
50	RPOR3290	O-ring	1
51	RPHD12051	Washer	1